



Stabilizer Pontoon Assembly and User's Manual

Items in your box:



- (2) Rotationally molded polyethylene pontoons
- (8) 1/4" X 1/2" stainless steel bolts
- (2) Female pontoon brackets
- (2) Male brackets
- (2) 1/4" stainless detent ring pins
- (2) Nylon lanyards

Tools Needed: Adjustable Wrench, Measuring Tape

Instructions for Assembly:




Take the two male brackets and, one at a time, attach them to each of the pontoons using (3) of the 1/4" X 1/2" bolts. Make sure the holes on the male brackets are facing the sides of the pontoons. Tighten to "pinky finger" tightness using your wrench.

Use the remaining 1/4" X 1/2" bolt to attach the final corner of the male bracket as well as one of the nylon lanyards.



Remove the bottom nut and washer from your rigger with an adjustable wrench. Slide the threaded bottom of your oarlock pin through the oval shaped hole in the base of the female bracket with the tube on the bracket facing upwards. Push the female bracket flush against the back of the block of the rigger, so that there is no play in the bracket. Re-attach the washer and nut and tighten with your wrench. Check the span/spread with a tape measure after installing your female bracket as this measurement may have changed during installation.

Instructions for Use:



Select the height of the pontoon by sliding the male bracket up or down in the female bracket. The height of your pontoon will determine how much your pontoon remains on or off the water while you row. When you have found your preferred height, secure the pontoon in place with the detent ring pin. Finding your perfect height might take getting on and off the water a couple of times with your pontoons attached to your boat to determine which height works best. If your pontoons are too low, they will cause a lot of splash. If they are too high, they may not give you the desired stability. Some rowers prefer the pontoons higher, using them only as a “safety net.” Although it is possible to adjust your pontoons on the water, it is always recommended to adjust them on land before or after you row.



When docking, remove your dockside pontoon completely before landing at the dock. DO NOT run your pontoon up on the dock as it will cause damage to your pontoon and your boat. If you do happen to strike a stationary or submerged object while you are rowing, your female brackets are designed to be sacrificial, so that you do not damage the expensive rigging on your boat.



Do not leave your dockside pontoon attached while at the dock as damage to your pontoon and your rigging may occur. Attach your dockside pontoon after you have launched.

At the end of each row, remove your pontoons from your shell. Release the drain plug to drain any water that may have collected and to allow the insides of the pontoons to air out.

Still have questions?

Please contact us directly: **770-561-9995** or info@revolutionrowing.com

Stabilizer Pontoon Guidelines

When using Revolution Rowing Stabilizer Pontoons, there are precautionary measures that the user must follow. The following list will guide you to use your product in a safe manner.

- Only use approved fasteners and mounting hardware provided by Revolution Rowing to assemble and attach your Stabilizer Pontoons to your rowing shell. Fasteners and hardware should be inspected periodically for wear, corrosion and fatigue.
- Never exceed the manufacturer's recommended weight limit for your rowing shell. Revolution Rowing Stabilizer Pontoons are not meant to be used as supplemental buoyant force to increase a rowing shell's capacity.
- Check the fasteners on your rigging and pontoons frequently for tightness. Hardware and fasteners can become loose during normal use.
- Know local, state and federal boating laws. Appropriate safety and navigational gear should be carried on board your vessel. Revolution Rowing Stabilizer Pontoons are not a life saving flotation device.
- Be aware of inclement weather and water conditions before you row. Do not go out in conditions that exceed your abilities. Do not strike objects with your Stabilizer Pontoons while rowing.
- Remove your Revolution Rowing Stabilizer Pontoons when not in use. Inspect for leaks and cracks that may compromise their flotation.
- Revolution Rowing Stabilizer Pontoons are not for use on motorized water craft.
- Consult Revolution Rowing if you have any questions about the operation or limitations of Revolution Rowing products.

Limited 30 Day Warranty

Effective September 3, 2015

Revolution Rowing will warranty all Revolution Rowing brand Stabilizer Pontoons manufactured by Revolution Rowing for a period of 30 days after purchase. This warranty is available to the original retail purchaser and will terminate if the purchaser transfers the product to any other person.

Subject to the limitations and exclusions described in this warranty, Revolution Rowing will remedy defects in materials or workmanship by repairing or replacing, at its option, a defective product without charge for parts or labor. In addition, Revolution Rowing may elect, at its option, not to repair or replace a defective product but rather issue to a purchaser a refund equal to the purchase price paid for the product, minus shipping charges.

No warranty is given for defects caused by normal wear and tear, cosmetic rust, scratches, accidents, unlawful vehicle operation, or modification of, or any types of repair of, a Revolution Rowing travel products other than those authorized by Revolution Rowing.

No warranty is given for defects resulting from conditions beyond Revolution Rowing's control including, but not limited to, misuse, overloading, or failure to assemble, mount or use the product in accordance with Revolution Rowing's written instructions or guidelines.

No warranty is given for Revolution Rowing products purchased outside of the United States.

In the event that a product is defective, the purchaser should contact Revolution Rowing via the contact information available at the web address at the bottom of this page.

In the event that a product needs to be returned to Revolution Rowing, Revolution Rowing will provide the purchaser with the appropriate mailing address and any additional instructions. Please note that the purchaser will be responsible for the cost of mailing the product to Revolution Rowing.

Disclaimer of Liability

Repair or replacement of a defective product or the issuance of a refund or credit (as determined by Revolution Rowing) is a purchaser's exclusive remedy under this warranty. Damage to a purchaser's vessel, cargo and/or to any other person or property is excluded.

This warranty is expressly made in lieu of any and all other warranties, express or implied.

Revolution Rowing's sole liability to any purchaser is limited to the remedy set forth above. In no event will Revolution Rowing be liable for any lost profits, lost sales, or for any consequential, direct, indirect, incidental, special, exemplary, or punitive damages or for any other damages of any kind or nature.